



CLAY DIKE TYPICAL CROSS SECTION
NO STAKE

Engineer's Recommendation:

1. Remove sod and top soil (clay to clay)
2. Top of berm 3 feet minimum.
3. 2 to 1 ratio for slope of sides.
4. Compact clay (very important)
5. Seed or sod as soon as possible.
6. No fence or trees in berm.